PT-301CB/PT-302CB User Manual

I. Hardware **specifications**：

1. Current Sinking: 150mA(Max.)@5V.
2. Frequency Response: 15~20KHz@-10dBV input signal.
3. Storage Temperature：-40℃～+85℃。
4. Operating Temperature：0℃～+40℃。
5. Machine Dimension：145X80X25mm。
6. Parts：Main body,USB cable（Type A〈-----〉Mini）。
7. Panel description：
   A. PT-302CB (Version RJ9)：



A1. Power LED：USB 5V power display.
A2. USB：connect to USB connector of PC.
A3. Headset：connect Plantronic PRACTICA SP11/12　Headset.

B. PT-301CB(Version Headset)



B1. Power LED：USB 5V Power Display.

B2. USB：connect to USB connector of PC.

B3. Earphone＆Mic：connect Plantronic PRACTICA SP11/12 Headset or normal speaker and micphone。

II. Setep of Operation Setting ：

III.

1. Please disable default audio device of pc as follows.




Control Panel ▸ System and Security ▸ System
Search Control Panel
Control Panel Home
Device Manager
Remote settings
System protection
Advanced system settings
View basic information about your computer
Windows edition
Windows 7 Home Premium
Copyright © 2009 Microsoft Corporation. All rights reserved.
Service Pack 1
Get more features with a new edition of Windows 7
Select Device Manager
System
Manufacturer: ASUSTeK COMPUTER INC.
Model: Eee Box Series
Rating: 3.6 Windows Experience Index
Processor: Intel(R) Atom(TM) CPU D2550 @ 1.86GHz 1.86 GHz
Installed memory (RAM): 2.00 GB
System type: 64-bit Operating System
Pen and Touch: No Pen or Touch Input is available for this Display
ASUSTeK COMPUTER INC. support
Website: Online support
Computer name, domain, and workgroup settings
Computer name: SMServer-PC
Change settings
Full computer name: SMServer-PC
Computer description:
Workgroup: WORKGROUP
Windows activation
Windows is activated
See also
Action Center
Windows Update
Performance Information and Tools
11:25 AM
9/19/2014


Device Manager
File Action View Help
SMServer-PC
Computer
Disk drives
Display adapters
Human Interface Devices
IDE ATA/ATAPI controllers
Keyboards
Mice and other pointing devices
Monitors
Network adapters
Portable Devices
Processors
Sound, video and game controllers
NVIDIA High Definition Audio
Realtek High Definition Audio
System devices
Universal Serial Bus controllers
1.Open Sound, video and Game Controller
11:33 AM
9/19/2014


Device Manager
File Action View Help
SMServer-PC
Computer
Disk drives
Display adapters
Human Interface Devices
IDE ATA/ATAPI controllers
Keyboards
Mice and other pointing devices
Monitors
Network adapters
Portable Devices
Processors
Sound, video and game controllers
NVIDIA High Definition Audi
Realtek High Definition Aud
System devices
Universal Serial Bus controllers
Update Driver Software...
Disable
Uninstall
Scan for hardware changes
Properties
1. Select audio device
2. Right button of mouse
3. Select Disable
Disables the selected device.
11:34 AM
9/19/2014


Device Manager
File Action View Help
SMServer-PC
Computer
Disk drives
Display adapters
Human Interface Devices
IDE ATA/ATAPI controllers
Keyboards
Mice and other pointing devices
Monitors
Network adapters
Portable Devices
Processors
Sound, video and game controllers
NVIDIA High Definition Audio
Realtek High Definition Audio
System devices
Universal Serial Bus controllers
NVIDIA High Definition Audio
Disabling this device will cause it to stop functioning. Do you really want to disable it?
Yes
No
Select Yes Botton
11:35 AM
9/19/2014



2. Connect USB cable to PC and PT-301CB/PT-302CB。

3. Device Manager Audio setting will be as follows.



4. Device Manager Sound Setting：

A. Speaker Volume Setting：




Control Panel
Search Control Panel
Adjust your computer's settings
View by: Category
System and Security
Review your computer's status
Back up your computer
Find and fix problems
Network and Internet
View network status and tasks
Choose homegroup and sharing options
Hardware and Sound
View devices and printers
Add a device
Programs
Install a program
User Accounts and Family Safety
Add or remove user accounts
Set up parental controls for any user
Appearance and Personalization
Change the theme
Change desktop background
Adjust screen resolution
Clock, Language, and Region
Change keyboards or other input methods
Ease of Access
Let Windows suggest settings
Optimize visual display
Hardware and Sound
Add or remove printers and other hardware, change system sounds, play CDs automatically, conserve power, update device drivers, and more.
1. Select Hardware and Sound

1:49 PM
9/22/2014


Control Panel
Hardware and Sound
Search Control Panel
Control Panel Home
System and Security
Network and Internet
Hardware and Sound
Programs
User Accounts and Family Safety
Appearance and Personalization
Clock, Language, and Region
Ease of Access
Devices and Printers
Add a device
Add a printer
Mouse
Device Manager
AutoPlay
Change default settings for media or devices
Play CDs or other media automatically
Sound
Manage audio devices
Sound
Configure your audio devices or change the sound scheme for your computer.
Change when the computer sleeps
Choose a power plan
Display
Adjust screen resolution
Connect to an external display
NVIDIA Control Panel
1. Select Sound

1:50 PM
9/22/2014





A1. Please choose another Speaker device，the setting same above step.

B. Microphone Volume Setting：







5. Application Software Operation setting (e.g Skype and SJphone),the Setep as follows.

A. Skype Setting：





B. SJphone setting：





IV. Other：

1. Support WIN 7,Linux。
2. PT-301CB/PT-302CB can make 3 conference call through different sip phone software e.g Skype and SJphone.